

for **Servicing** value, try us
Fixed Price Servicing, Levels 1-4

Level 1 £99.00 inc.

Level 2 £169.00 inc.

Level 3 £235.00 inc.

Level 4 £342.00 inc.

Fixed price servicing applicable to Honda's over 3 years of age and engines up to 4 cylinders. Includes parts labour and VAT (*excludes platinum plugs*).

For Diesels and vehicles on fully synthetic oil an extra charge will be applicable.

Diesel engine oil £36.00 inc. extra. Fully synthetic oil £26.00 inc. extra.

**Crown Motors Bushey Heath
(Distributors) Ltd.**

46-52 High Road, Bushey Heath, Herts. WD23 1GQ.

Telephone: 020 8950 3311 Fax: 020 8421 7373

service@crownhonda.co.uk

**Crown Motors Ltd.
(Hendon)**

The Hyde, Edgware Road, Hendon NW9 6TH.

Telephone: 020 8200 4040 Fax: 020 8205 0900

service.hendon@crownhonda.co.uk

www.crownhonda.co.uk

Open Monday to Saturday



Checklist

		LEVEL 1	LEVEL 2	LEVEL 3	LEVEL 4
1	Note any damage to body or upholstery	◆	◆	◆	◆
2	Fit car protection kit	◆	◆	◆	◆
3	Check operation of all lights	◆	◆	◆	◆
4	Lubricate all doors, locks, hinges, bonnet hinge & safety catch	◆	◆	◆	◆
5	Check condition of wiper blades	◆	◆	◆	◆
6	Test screen wash operation, adjust/top up	◆	◆	◆	◆
7	Visually inspect cooling system for leaks and test antifreeze strength	◆	◆	◆	◆
8	Inspect condition of Alternator & PAS belts	◆	◆	◆	◆
9	Inspect brake fluid levels	◆	◆	◆	◆
10	Top up battery levels	◆	◆	◆	◆
11	Top up power steering fluid level	◆	◆	◆	◆
12	Fit new oil filter	◆	◆	◆	◆
13	Drain and refill engine oil	◆	◆	◆	◆
14	Inspect brake linings, front (% Left) <input type="checkbox"/> N/S Front <input type="checkbox"/> O/S Front	◆	◆	◆	◆
15	Inspect brake linings, rear (% Left) <input type="checkbox"/> N/S Rear <input type="checkbox"/> O/S Rear	◆	◆	◆	◆
16	Torque wheel nuts to correct setting	◆	◆	◆	◆
17	Inspect tyres and set tyre pressures (mm) N/S Front <input type="checkbox"/> O/S Front <input type="checkbox"/> N/S Rear <input type="checkbox"/> O/S Rear <input type="checkbox"/>	◆	◆	◆	◆
18	Assess brake performance & overall performance of steering & suspension on road test	◆	◆	◆	◆
19	Check for abnormal noises on road test	◆	◆	◆	◆
20	Check operation of heating system	◆	◆	◆	◆
21	Check operation and condition of seat belts	◆	◆	◆	◆
22	Check operation of air conditioning system and check cabin filter	◆	◆	◆	◆
23	Wash and leather	◆	◆	◆	◆
24	Provide defect report	◆	◆	◆	◆
25	Inspect brake hoses and pipes	◆	◆	◆	◆
26	Inspect suspension mountings	◆	◆	◆	◆
27	Inspect shock absorbers	◆	◆	◆	◆
28	Inspect drive shaft, joints and gaiters	◆	◆	◆	◆
29	Inspect track rod ends	◆	◆	◆	◆
30	Examine condition of exhaust and hangers	◆	◆	◆	◆
31	Refit road wheels (rotate tyres if required)	◆	◆	◆	◆
32	Assess engine performance and oil levels	◆	◆	◆	◆
33	Check clutch for free play	◆	◆	◆	◆
34	Check gear shift quality/auto gearbox operation	◆	◆	◆	◆
35	Check steering for stability, pull or wander	◆	◆	◆	◆
36	Check operation of instruments	◆	◆	◆	◆
37	Fit new air filter	◆	◆	◆	◆
38	Carry out diagnostic tune	◆	◆	◆	◆
39	Fit new spark plugs*	◆	◆	◆	◆
40	Check horn operation and tone	◆	◆	◆	◆
41	Check heated rear screen	◆	◆	◆	◆
42	Check electric equipment if fitted: central locking, windows, sunroof & mirrors	◆	◆	◆	◆
43	Pressure test cooling systems	◆	◆	◆	◆
44	Lubricate linkages and cables	◆	◆	◆	◆
45	Adjust handbrake	◆	◆	◆	◆
46	Check prop shaft and universal joints	◆	◆	◆	◆
47	Inspect fuel tank for leaks	◆	◆	◆	◆
48	Inspect under body for corrosion	◆	◆	◆	◆
49	Examine steering rack for play and oil leaks	◆	◆	◆	◆
50	Check power steering hoses/pumps for leaks	◆	◆	◆	◆
51	Check wheel bearings and ball joints	◆	◆	◆	◆
52	Top up gearbox oil level	◆	◆	◆	◆
53	Lubricate brake back plates, slide points and handbrake levers	◆	◆	◆	◆
54	Ensure caliper operation is normal	◆	◆	◆	◆
55	Top up differential level	◆	◆	◆	◆
56	Check and adjust tappets (if necessary)	◆	◆	◆	◆
57	Replace brake fluid	◆	◆	◆	◆
58	Check Tracking	◆	◆	◆	◆